

Changing from DryRoll to WetRoll on a Heidelberg with CP2000 or Press Center

1. With the **CP 2000** you can adjust the amount of wash and water and as well the time of this process. Choose on the CP 2000 display the program Washing and then Service. There you must reduce the amount of wash to 0, also the wash circles must be reduced to 0. Then press confirm and start. In most cases the printer knows the procedure very well and he will adjust the system easily.
2. With the **HD Press Center** it is similar, but usually there is a pass word to fill in. It is – if not changed on purpose – 3 of 4 times 0. Then you can establish a new washing program, i.e. program 5 is for **WetRoll**: wash to reduce to 0, and water down to 10-20. Then you can switch easily from **DryRoll** to **WetRoll** and vice a verse.