

DELETION FLUID MP | MP-S

For the Minus Correction/Deletion of Positive-Offset Plates + Ctp Thermal Plates

FEATURES AND BENEFITS:

- Easy to spread paste:
very precise deletion possible
- Performs thixotrope:
NO "Bleeding" effect
- Corrects gentle:
does not attack the oxide surface of the plate
- Low pour

For all popular Positive Plates and CTP Thermal Plates

DIRECTIONS:

Apply with a brush, let penetrate ca. 10 – 15 seconds, then remove with a wet sponge.

By shaking the DELETIONS FLUID MP the viscosity can be reduce to the desired level. After some time the former pasty form is coming back again.

For difficult to correct positive plate the more aggressive DELETION FLUID MP-S is recommended.

PACKAGING:

100 ml PE-bottle (16 bottles per carton)

