

Ultrasonic Cleaner RAM 08

Cleaner Concentrate for Ultrasonic Baths



Product Usage

Cleaner Concentrate for Ultrasonic Baths

Packaging

10 liter can

Storage and Shelf Life

Storage: not under 8°C, not above 40°C

Shelf Life: 12 months

Keep can tightly closed

Keep away from direct sunlight

Features and Benefits

- high performance surfactants support the cleaning process
- strong emulsifiers bind the soils and residues
- gentle solvents remove the residues
- corrosion inhibitors protect metal surfaces

Directions

Mix 1 part RAM 08 Cleaner Concentrate with 4 parts of water - fill into the ultrasonic bath and let penetrate for 20-30 minutes at a higher temperature of ca. 40°C. Remove parts and dry with a rag. Depending on the grade of contamination a dilution up to 1:9 with water may work as well

Technical Specifications

- form: liquid
- Density: 1,00 g/cm³
- Color: light blue
- Odour: neutral
- Water miscible: yes
- pH value: 10,8
- hazards classification: Attention